



WWW.eueejeeog.com

Product Features





- Ergonomic comfort hand grip
- Battery charger LED indicator and socket
- Obedience training whistle
- Forward and downward LED lights
- Carabiner clip and lanyard
- Adjustable height control
- Snap-on auger cap
- Pick-up/drop-off switch/lock
- Easy action trigger
- 10 Cleaning solution
- Foot operated cleaning station with flip cap

Your next best friend!



Important Safeguards

When using battery operated devices, basic safety precaution should be followed to reduce risk of injury and include, but are not limited to the following;

- 1. Read all instructions
- 2. Do not place fingers or loose clothing near auger when in use. Avoid contact with moving parts.
- 3. Not recommended for use by children under 10
- 4. Do not hang your Auggie Dog by the wrist strap
- 5. Do not charge the battery for longer than 10 hours
- 6. Auggie Dog will not operate if jammed. Reverse direction to remove the blockage, do not attempt to remove items in the auger yourself
- 7. Do not use your Auggie Dog for anything other than its intended use.
- 8. Do not submerse trigger/handle in water
- 9. Do not operate if your Auggie Dog has been damaged
- 10. WARNING: To reduce risk of electrical shock or injury do not attempt to open your Auggie Dog. There are no user serviceable parts inside. Repair should only be done by an authorized dealer.

Charging Instructions

Your Auggie Dog comes with a charging adaptor. This adaptor has a polarized plug (one blade is wider than the other). To reduce risk of shock, this plug will only fit in a polarized outlet one way. If the plug does not fit reverse the plug and try again. If it still does not fit contact a qualified electrician. *Do not modify the plug in any way.*

To charge your Auggie Dog plug the adaptor into the wall and the jack into the charging input. Shown as number 2 on your diagram.

Your first charge should be no longer than 6 hours. Charge as needed after initial charge. The charge status indicator will be red while charging and green when fully charged. Avoid over charging.

Charge duration will vary according to use. Daily users can expect up to two weeks of use between charges.

Important: All functions of the Auggie Dog are inoperable while charging.



Using your Auggie Dog

1. Ensure that you have followed the charging instructions previously outlined.

2. If your Auggie Dog is attached to the standing cap (#7) remove prior to use. This can be done by holding your foot against the edge of the standing cap and rotating the Auggie Dog counter-clockwise and lifting the Auggie Dog.

3. Unlock shaft height adjuster (#6) and extend telescoping shaft to desired height prior to use.

4. Auggie Dog has two directions of auger operation. Collect (lift) indicated by an upward spiral of the left of the handle and Empty (lower) on the right side of the handle. Choose your direction by pressing the Toggle Switch (#8). Also note that when the Toggle Switch is in the middle position the auger is locked. You should be in this position when not in use.

5. Auger action (on/off) is controlled by the Trigger (#9). Depress the trigger to start the auger and release to stop operation. Note: There is only one speed.

6. To pick up feces follow the following;

- a) Hold the Auggie Dog by the grip and select the Collect (lift) function as explained earlier
- b) Engage the auger trigger (#9)
- c) Center auger barrel over feces
- d) Lower the barrel opening over feces while auger is spinning
- e) Release trigger and raise the Auggie Dog
- f) If feces remain repeat instructions b-e
- g) Return Toggle Switch to middle (safety) position

7. Auggie Dog is equipped with a safety feature that stops operation of the lifting feature should the barrel become too full or jammed. An audible clicking sound accompanies this feature. If this occurs, discontinue collecting and empty contents. Re-collect the feces without the obstructing material. This could be small stones, acorns, dirt, etc.

8. To dispose of collected material place the auger over a collection bin or composter and set the toggle switch (#8) to empty. Depress trigger (#9) and empty contents. Continue operation until no further material leaves the barrel.

Note: Please check with your local by-laws for acceptable disposal sites.

Your next best friend!

Cleaning your Auggie Dog

Once empty a quick visit to the cleaning station will have your Auggie Dog ready for your next walk.

1. Pour contents of Auggie Dog Aromatic cleaning solution up to the fill line as indicated on the inside of the cleaning pail. (To order additional cleaning solution please visit <u>www.theauggiedog.com</u>) Note: Auggie Dog cleaning solution is Septic friendly

2. Place pail in convenient location. Avoid areas where temperature could drop below freezing as the solution could freeze. (Additional cleaning stations can also be ordered at <u>www.theauggiedog.com</u>)

3. Raise the lid by stepping on the foot pedal and insert the auger barrel into the pail until it rests on the bottom.

4. With the devise in the Collect-Lift position (#8) depress the trigger (#9) to lift cleaning solution into the auger for up to 10 seconds. Reverse auger direction and run for 10 seconds. Repeat as necessary to ensure cleanliness.

5. You can store your Auggie Dog in the cleaning station or it can be removed and capped to be stored separately.

6. It is recommended that you change the cleaning solution at least once per week. Heavy usage may require more frequent cleaning.

7. To change the cleaning solution depress foot pedal to raise the lid. Lift out the solution holder (#11) by means of the wire handle. Twist to remove the pail and clean in an appropriate area. Reinsert pail and lock into position. Refill cleaning solution and close the lid.

Added Features of Auggie Dog

You will soon come to find that your new Auggie Dog is more than just a collection device.

- Enhanced Visibility: Headlight with on/off switch to make night time operation easy and ensures user is visible to others
- Enhanced Safety: Reflective graphics on barrel and shaft provide safety for night time walkers
- Convenient wrist strap
- Obedience training whistle: Momentary switch integrated with light switch for a helpful training tool (Please visit <u>www.theauggiedog.com</u> for helpful training tips)







Beyond Walking your Dog

Auggie Dog is your next best friend. It is the ultimate yard maintenance tool for those of you that let your pets run in your yard.

Weekly clean up just got a whole lot easier. Large volume and past pick up.

We know that you are going to love your Auggie Dog and we welcome your feedback. Please visit <u>www.theauggiedog.com</u> often and send us your comments.

Warranty Information

Limited One Year Warranty Warranty covers manufacturers' defects Original proof of purchase is required This warranty excludes all incidental or consequential damages.

Please contact our distributor GCL Solutions Group for warranty issues.

GCL Solutions Group 19-350 Harry Walker Parkway North Newmarket, Ontario L3Y 8L3 877-898-8408 sales@gclsolutions.com

